

Metal Mailbox Post

Installation Instructions

Product Dimensions

- 4" x 4" post
- 6.5" x 6.5" base and cap
- 41" or 58" height
- 3/8" mounting holes

Included Hardware

- Post
- 4 bolts



Step 1) Set post height

The Metal Mailbox Post can be 41", or 58" in height. We recommend about 41" above ground as a comfortable height to access your mailbox. If you choose to bury the post, we recommend adjusting the post to 58", digging a hole (18" deep min.), and mounting the post in cement.

To adjust post height to 58":

- 1) Remove the single, attached bolt using a wrench (not included)



Using Socket Wrench



Using Wrench



Remove screw

Step 1) Set post height (...continued)

2) Extend post base to find threaded hole.



Lift post to not scratch



Match hole with thread



Start screw by hand

3) Install bolts to all 4 threaded holes using wrench or socket wrench.

Step 2) Mount Post

The Metal Mailbox Post may be bolted to the ground or buried and cemented in. Please consider the following when mounting post:

1) Ensure the post "sleeve" is on top. This helps to protect the post from water and weather.



BAD: Sleeve is on bottom



GOOD: Sleeve is on top



Post is protected from water

Step 2) Mount Post (*...continued*)

2) We recommend you bury base of post and cement in (58"), or bolt base to ground (41").



18" hole is recommended



Leave appr. 41" above ground



Bracket holes used to mount